


D0509



Codo 90° rosca macho UNF asiento JIC 37° a rosca hembra giratoria UNF asiento JIC 37°



N° Código	Diámetro Exterior Tubo	Tamaño de Rosca	
		Rosca "A" JIC	Rosca "B" JIC
D0509-02-02	1/8"	5/16"-24	5/16"-24
D0509-03-03	3/16"	3/8"-24	3/8"-24
D0509-04-04	1/4"	7/16"-20	7/16"-20
D0509-05-05	5/16"	1/2"-20	1/2"-20
D0509-06-06	3/8"	9/16"-18	9/16"-18
D0509-08-08	1/2"	3/4"-16	3/4"-16
D0509-10-10	5/8"	7/8"-14	7/8"-14
D0509-12-12	3/4"	1 1/16"-12	1 1/16"-12
D0509-14-14	7/8"	1 3/16"-12	1 3/16"-12
D0509-16-16	1"	1 5/16"-12	1 5/16"-12
D0509-20-20	1 1/4"	1 5/8"-12	1 5/8"-12
D0509-24-24	1 1/2"	1 7/8"-12	1 7/8"-12
D0509-32-32	2"	2 1/2"-12	2 1/2"-12

D0510

Pasachapa recto rosca macho UNF asiento JIC 37° a rosca macho UNF asiento JIC 37°



N° Código	Diámetro Exterior Tubo	Tamaño de Rosca	
		Rosca "A" JIC	Rosca "B" JIC
D0510-02-02	1/8"	5/16"-24	5/16"-24
D0510-03-03	3/16"	3/8"-24	3/8"-24
D0510-04-04	1/4"	7/16"-20	7/16"-20
D0510-05-05	5/16"	1/2"-20	1/2"-20
D0510-06-06	3/8"	9/16"-18	9/16"-18
D0510-08-08	1/2"	3/4"-16	3/4"-16
D0510-10-10	5/8"	7/8"-14	7/8"-14
D0510-12-12	3/4"	1 1/16"-12	1 1/16"-12
D0510-14-14	7/8"	1 3/16"-12	1 3/16"-12
D0510-16-16	1"	1 5/16"-12	1 5/16"-12
D0510-20-20	1 1/4"	1 5/8"-12	1 5/8"-12
D0510-24-24	1 1/2"	1 7/8"-12	1 7/8"-12
D0510-32-32	2"	2 1/2"-12	2 1/2"-12